9. Schematic Diagrams

9-1 Schematic Diagrams (This Document can not be used without Samsung's authorization)





CONDITION OF OVEN

DOOR IS OPENED
COOK OFF

WIRING COLOR

BRN : BROWN
WHT : WHITE
RED : RED
Y/G : YELLOW/GREEN
BLU : BLUE
ORG : ORANGE
YEL : YELLOW
PNK : PINK



PRIMARY LATCH SWITCH

DOOR SENSING SWITCH

MONITOR SWITCH



SYMBOL	COLOR
ORG	ORANGE
BRN	BROWN
BLK	BLACK
RED	RED
BLU	BLUE